


Funter Bay SMP, SE07-11

Center of map at 58° 14.48' N Lat., 134° 53.68' W Lon.

Geographic Response Strategies for Southeast Alaska Subarea, Zone 7



This is not intended for navigational use.



EX01b&c viewed from the south.



EX01d viewed from the south.

Map Legend

-  Free-oil Recovery
-  Exclusion Booming
-  Protected-water Boom
-  Bears in Area, Guards Recommended

ID	Location and Description	Response Strategy	Implementation	Response Resources	Staging Area	Site Access	Resources Protected	Special Considerations
SE07-11-01 	Funter Bay SMP Funter Creek a. Lat. 58° 14.13'N Lon. 134°53.33'W Crab Cove Creek b. Lat. 58° 15.31'N Lon. 134°52.49'W c. Lat. 58° 15.34'N Lon. 134°53.03'W Coot Cove Creek d. Lat. 58° 15.32'N Lon. 134°54.28'W	Exclusion Exclude oil from entering the identified creeks in Funter Bay.	Deploy anchors and boom with skiffs (class 6). Place protected-water boom in a chevron pattern in front of the entrance to designated creeks/rivers. For arrays (b) & (c) use the island as an anchoring point and extend the array to shore to complete the exclusion. Tend throughout the tide. <u>Boom Lengths:</u> a. 800 ft. b. 600 ft. c. 550 ft. d. 200 ft.	Deployment Equipment 2150 ft. protected-water boom 11 ea. anchor systems 16 ea. anchor stakes Vessels 1 ea. class 3 2 ea. class 6 Personnel/Shift 7 ea. vessel crew Tending Vessels 1 ea. class 6 1 ea. class 3 Personnel/Shift 5 ea. vessel crew	Vessel Platform	Via marine waters Chart 17316_2	Fish: pink, chum, coho, dolly varden, Birds: seabird nesting Habitat: marsh, exposed tidal flats, sheltered rocky shore Human Use: high recreational use, subsistence	Vessel master should have local knowledge. Bear are present in the area. Bear guard required. Consult with Incident Command to ensure ADFG-Title 16 and ADNR-Title 41 permits have been obtained. Consult the Site Selection Matrix for cultural resources designation. Consult the ADEC "Spill Tactics for Alaska Responders" manual for additional information on the deployment of these tactics. Survey: not yet Tested: not yet
SE07-11-02 	Funter Bay SMP Nearshore waters in the general area of: Lat. 58° 14.30'N Lon. 134°54.55'W	Free-oil Recovery Maximize free-oil recovery in the offshore & nearshore environment of Funter Bay SMP depending on spill location and trajectory.	Deploy free-oil recovery strike teams upwind and up current of Funter Bay SMP. Use aerial surveillance to locate incoming slicks.	Deploy multiple free-oil recovery strike teams as required to maximize interception of oil before it impacts sensitive areas.	Hoonah- 21nm-via marine access	Via marine waters Chart 17316_2	Same as SE07-11-01	Vessel master should have local knowledge. Use extreme caution, shoal waters with numerous reefs and rocks, shallow mud flats and channels.

NOTE: Sensitive resource information can be found on other maps which can be accessed through the sensitive area section of the SE AK Sub-Area Contingency Plan: http://www.dec.state.ak.us/spar/perp/plans/scp_se.htm.